

How to Restart

Your Micro Market



To Restart a Kiosk:

- 1 Power off / unplug the kiosk.
- 2 Wait 15-20 seconds.
- 3 Power on / plug the kiosk back in.

** The kiosk will boot up to the welcome screen.

To Restart a Smart Lock:

- 1 Power off the smart lock.
- 2 Wait 15-20 seconds.
- 3 Plug the smart lock back into power.

** If the lock is connected there will be a red/green light.

To Restart a Cooler Cafe:

- 1 Insert a paperclip into the pinhole on the right-hand side for 5 seconds.
- 2 The terminal will restart.

Need some help?

P: 715.386.2233

E: contact@cantaloupe.com